

Joint Crediting Mechanism Approved Methodology ID_AM009

“Replacement of conventional burners with regenerative burners for aluminum holding furnaces”

A. Title of the methodology

Replacement of conventional burners with regenerative burners for aluminum holding furnaces, ver. ~~32~~.0

B. Terms and definitions

Terms	Definitions
Regenerative burner	Burner systems which absorb exhaust gas heat to a reservoir and preheat combustion air using the absorbed heat in the reservoir to improve energy efficiency.
Conventional burner	Burner systems which do not have combustion air preheating facility.
Periodical check	Periodical investigation of furnace done by manufacturer or agent who is authorized by the manufacturer, in order to maintain furnace performance.

C. Summary of the methodology

Items	Summary
<i>GHG emission reduction measures</i>	By replacing conventional burners with regenerative burners for aluminum holding furnaces, consumption of natural gas is reduced, which leads to the reduction of GHG emissions.
<i>Calculation of reference emissions</i>	Reference emissions are the CO ₂ emissions from the use of reference burners in an aluminum holding furnace, which are calculated based on the consumption of natural gas in the project furnace and energy efficiency of the reference and project burners.
<i>Calculation of project emissions</i>	Project emissions are the CO ₂ emissions from the use of project burners in an aluminum holding furnace, which are calculated based on the consumption of natural gas and electricity in the project furnace.

Items	Summary
<i>Monitoring parameters</i>	<ul style="list-style-type: none"> - Consumption of natural gas by the project furnace - The number of operating days

D. Eligibility criteria

This methodology is applicable to projects that satisfy all of the following criteria.

Criterion 1	The project replaces conventional burners with regenerative burners for aluminum holding furnaces.
Criterion 2	Holding temperature of aluminum melt, which is determined in the furnace user's specification, is within the range from 600 to 800 degrees Celsius.
Criterion 3	The regenerative burners have a structure which leads all exhaust gas to flow through the heat reservoir before discharging it into the atmosphere.
Criterion 4	Periodical check is planned at least once a year.

E. Emission Sources and GHG types

Reference emissions	
Emission sources	GHG types
Combustion of natural gas in the reference furnace	CO ₂
Project emissions	
Emission sources	GHG types
Combustion of natural gas in the project furnace	CO ₂
Power consumption by the project furnace	CO ₂

F. Establishment and calculation of reference emissions

F.1. Establishment of reference emissions

The methodology results in conservative calculation of emission reductions and ensures net reduction of emissions by the following approaches:

1. Setting energy efficiencies of burners in a conservative manner

It can be said that the energy efficiency of burners increases as the exhaust gas temperature falls (and vice versa), since high exhaust gas temperature means that heat is released without being used. In this methodology, the energy efficiencies are set as default values by assuming the

exhaust gas temperature conservatively.

For the reference burner, the exhaust gas temperature is set as 750 degrees Celsius. When the holding temperature is designed to be within the range from 600 to 800 degrees Celsius, the actual furnace atmospheric temperature is generally in the range of 750 to 950 degrees Celsius. Therefore, for the reference burner, the exhaust gas temperature is assumed to be equal to the lower end of furnace atmospheric temperature for the sake of conservativeness.

For the project burner, the exhaust gas temperature is set as 300 degrees Celsius. When the holding temperature is designed to be within the range from 600 to 800 degrees Celsius, the actual furnace atmospheric temperature is generally in the range of 750 to 950 degrees Celsius for project burner, too. In addition, for the project burner, the exhaust gas temperature is lower than the furnace atmospheric temperature due to the heat absorber; when the furnace atmospheric temperature is in the range of 750 to 950 degrees Celsius, the possible temperature of the project exhaust gas is less than 300 degrees Celsius. Therefore, for the project burner, the exhaust gas temperature is set as the upper end of the possible exhaust gas temperature for the sake of conservativeness.

Therefore, this methodology results in the conservative calculation of reference emissions by assuming the lower reference exhaust gas temperature and the higher project exhaust gas temperature in setting the burner efficiencies.

2. Omitting reference power consumption

Although electricity is used in the reference furnace, CO₂ emissions from power consumption are not included in the reference emissions for the purpose of ensuring simplicity and conservativeness.

F.2. Calculation of reference emissions

Reference emissions are calculated as follows:

$$RE_p = \sum_i \{ FC_{PJ,NG,i,p} \times (\eta_{PJ,i} \div \eta_{RE,i}) \times NCV_{NG} \times EF_{NG} \}$$

Where:

RE _p	Reference emissions during the period <i>p</i> [tCO ₂ /p]
FC _{PJ,NG,i,p}	Consumption of natural gas by the project furnace <i>i</i> during the period <i>p</i> [Nm ³ /p]
η _{PJ,i}	Energy efficiency of the project burner of the project furnace <i>i</i> [-]

$\eta_{RE,i}$	Energy efficiency of the reference burner of the project furnace i [-]
NCV_{NG}	Net calorific value of natural gas [GJ/Nm ³]
EF_{NG}	CO ₂ emission factor of natural gas [tCO ₂ /GJ]

G. Calculation of project emissions

Project emissions are calculated as follows:

$$PE_p = PE_{NG,p} + PE_{elec,p}$$

Where:

PE_p	Project emissions during the period p [tCO ₂ /p]
$PE_{NG,p}$	Project emissions from natural gas consumption during the period p [tCO ₂ /p]
$PE_{elec,p}$	Project emissions from electricity consumption during the period p [tCO ₂ /p]

$$PE_{NG,p} = \sum_i (FC_{PJ,NG,i,p} \times NCV_{NG} \times EF_{NG})$$

Where:

$PE_{NG,p}$	Project emissions from natural gas consumption during the period p [tCO ₂ /p]
$FC_{PJ,NG,i,p}$	Consumption of natural gas by the project furnace i during the period p [Nm ³ /p]
NCV_{NG}	Net calorific value of natural gas [GJ/Nm ³]
EF_{NG}	CO ₂ emission factor of natural gas [tCO ₂ /GJ]

$$PE_{elec,p} = EC_{PJ,p} \times EF_{elec}$$

Where:

$PE_{elec,p}$	Project emissions during the period p (from electricity) [tCO ₂ /p]
$EC_{PJ,p}$	Consumption of electricity by the project furnace during the period p [MWh/p]
EF_{elec}	CO ₂ emission factor for consumed electricity [tCO ₂ /MWh]

$$EC_{PJ,p} = \sum_i \{ RC_{CAP,i} \times 10^{-6} \times 24(\text{hours/day}) \times D_{op,i,p} \}$$

Where:

$EC_{PJ,p}$	Consumption of electricity by the project furnace during the period p [MWh/p]
$RC_{CAP,i}$	The total maximum rated capacity of auxiliary equipment of the project furnace i [W]
$D_{op,i,p}$	The number of operating days of the project furnace i during the period p [day/p]

H. Calculation of emissions reductions

Emissions reductions are calculated as follows:

$$ER_p = RE_p - PE_p$$

Where:

ER_p Emissions reductions during the period p [tCO₂/ p]

RE_p Reference emissions during the period p [tCO₂/ p]

PE_p Project emissions during the period p [tCO₂/ p]

I. Data and parameters fixed *ex ante*

The source of each data and parameter fixed *ex ante* is listed as below.

Parameter	Description of data	Source
NCV_{NG}	Net calorific value of natural gas [GJ/Nm ³] The IPCC value is converted by gas composition and molecular weight. The default value for NCV_{NG} is set as 0.036659 GJ/Nm ³ .	IPCC Special Report on Carbon dioxide Capture and Storage, Annex I, Table AI.10. Lower Heating Value (LHV) is applied.
EF_{NG}	CO ₂ emission factor of natural gas [tCO ₂ /GJ]	Country specific data or IPCC default value from “2006 IPCC Guidelines for National Greenhouse Gas Inventory”. Lower limit value of the default CO ₂ emission factor is applied.
$\eta_{RE,i}$	Energy efficiency of the reference burner of the project furnace i [-] The project-specific value is calculated by the equation in explanatory note 1 using the recommended operational value of air	See explanatory note 1.

Parameter	Description of data	Source
	ratio in the manual of the project burner.	
$\eta_{PJ,i}$	Energy efficiency of the project burner of the project furnace i [-] The project-specific value is calculated by the equation in explanatory note 2 using the recommended operational value of air ratio in the manual of the project burner.	See explanatory note 2.
m_r	Air ratio for the reference burner The same value as air ratio for the project burner (m_p) is applied.	The recommended operational value in the manual of the project burner
m_p	Air ratio for the project burner	The recommended operational value in the manual of the project burner
EF_{elec}	CO ₂ emission factor for consumed electricity. When the project furnace consumes only grid electricity or captive electricity, the project participant applies the CO ₂ emission factor respectively. When the project furnace may consume both grid electricity and captive electricity, the project participant applies the CO ₂ emission factor with lower value. [CO ₂ emission factor] For grid electricity: The most recent value available from the source stated in this table at the time of validation For captive electricity: 0.8* [tCO ₂ /MWh] *The most recent value available from CDM approved small scale methodology AMS-I.A at the time of validation is applied.	[Grid electricity] The data is sourced from “Emission Factors of Electricity Interconnection Systems”, National Committee on Clean Development Mechanism (Indonesian DNA for CDM), based on data obtained by Directorate General of Electricity, Ministry of Energy and Mineral Resources, Indonesia, unless otherwise instructed by the Joint Committee. [Captive electricity] CDM approved small scale methodology AMS-I.A
$RC_{CAP,i}$	The total maximum rated capacity of auxiliary equipment of the project furnace	Specification or nameplate of auxiliary equipment of the project

Parameter	Description of data	Source
	[W]	furnace

(Explanatory note 1)

$$\eta_{RE} = \frac{NCV_{NG} - [G_{WNG} * c_{1,r} * (T_{1,r} - T_2) + A_{0,NG} * (m_r - 1) * c_{2,r} * (T_{1,r} - T_2)]}{NCV_{NG}}$$

Where:

- η_{RE} Energy efficiency of the reference burner [-]
- NCV_{NG} Net calorific value of natural gas: the default value for NCV_{NG} is set as **36,659** [kJ/Nm³] based on *IPCC Special Report on Carbon dioxide Capture and Storage*, Annex I, Table AI.10, and it is converted by gas composition and molecular weight.
- G_{WNG} Theoretical volume of wet exhaust gas from combustion of natural gas: the default value for G_{WNG} is set as **10.694** [Nm³/Nm³] based on the assumed natural gas composition of CH₄: 94.4%, C₂H₆: 3.1%, C₈H₈: 0.5%, and C₄H₁₀: 0.2% based on *IPCC Special Report on Carbon dioxide Capture and Storage*, Annex I, Table AI.10.
- $c_{1,r}$ Average specific heat at constant pressure of wet exhaust gas of natural gas, at the reference temperature of exhaust gas: the default value for $c_{1,r}$ is set as **1.455** [kJ/ Nm³·degree Celsius] based on the aforementioned natural gas composition and JIS G 0702, Appendix Table 2 (linear prediction is used for the estimation).
- $T_{1,r}$ Reference temperature of exhaust gas: the default value for $T_{1,r}$ is set as **750** [degrees Celsius].
- T_2 Ambient temperature (annual average in Jakarta): the default value for T_2 is set as **32.6** [degrees Celsius].
- $A_{0,NG}$ Theoretical amount of air of the natural gas: the default value for $A_{0,NG}$ is set as **9.688** [Nm³/Nm³] based on the aforementioned natural gas composition.
- m_r Air ratio for the reference burner: the same value as air ratio for the project burner (m_p) applied.
- $c_{2,r}$ Average specific heat at constant pressure of air, at the reference temperature of exhaust gas: the default values for $c_{2,r}$ is set as **1.380** [kJ/ Nm³·degree Celsius] based on the aforementioned natural gas composition and JIS G 0702, Appendix Table 2 (Linear prediction is used for the estimation).

(Explanatory note 2)

$$\eta_{PJ} = \frac{NCV_{NG} - [G_{WNG} * c_{1,p} * (T_{1,p} - T_2) + A_{0,NG} * (m_p - 1) * c_{2,p} * (T_{1,p} - T_2)]}{NCV_{NG}}$$

Where:

- η_{PJ} Energy efficiency of the reference burner [-]
- NCV_{NG} Net calorific value of natural gas: the default value for NCV_{NG} is set as **36,659** [kJ/Nm³] based on *IPCC Special Report on Carbon dioxide Capture and Storage*, Annex I, Table AI.10, and it is converted by gas composition and molecular weight.
- G_{WNG} Theoretical volume of wet exhaust gas from combustion of natural gas: the default value for G_{WNG} is set as **10.694** [Nm³/Nm³] based on the assumed natural gas composition of CH₄: 94.4%, C₂H₆: 3.1%, C₈H₈: 0.5%, and C₄H₁₀: 0.2% based on *IPCC Special Report on Carbon dioxide Capture and Storage*, Annex I, Table AI.10.
- $c_{1,p}$ Average specific heat at constant pressure of wet exhaust gas of natural gas, at the project temperature of exhaust gas: the default value for $c_{1,p}$ is set as **1.368** [kJ/Nm³·degree Celsius] based on the aforementioned natural gas composition and JIS G 0702, Appendix Table 2 (linear prediction is used for the estimation).
- $T_{1,p}$ Project temperature of exhaust gas: the default value for $T_{1,p}$ is set as **300** [degrees Celsius].
- T_2 Ambient temperature (annual average in Jakarta): the default value for T_2 is set as **32.6** [degrees Celsius].
- $A_{0,NG}$ Theoretical amount of air of the natural gas: the default value for $A_{0,NG}$ is set as **9.688** [Nm³/Nm³] based on the aforementioned natural gas composition.
- m_p Air ratio for the project burner: the recommended operational value in the manual of the project burner.
- $c_{2,p}$ Average specific heat at constant pressure of air, at the *project* temperature of exhaust gas: the default values for $c_{2,p}$ is set as **1.319** [GJ/Nm³·degree Celsius] based on the aforementioned natural gas composition and JIS G 0702, Appendix Table 2 (Linear prediction is used for the estimation).

History of the document

Version	Date	Contents revised
<u>03.0</u>	<u>24 October 2018</u>	<u>Revision to:</u> <u>Change the description of “Measurement methods and procedures” to clarify the requirement for calibration in the Monitoring Spreadsheet: JCM_ID_AM009</u>
02.0	10 February 2017	JC6, Annex 4

		Revisions to: <ul style="list-style-type: none">● Change the description of energy efficiency of the reference burner of the project furnace i in Section I.● Change the description of air ratio for the reference burner (m_r) in Section I and Explanatory note 1; and● Change the status of parameter “air ratio for the reference burner” from default value to a parameter fixed <i>ex ante</i> in the Monitoring Spreadsheet.
01.0	6 August 2015	Electronic decision by the Joint Committee Initial approval.

Monitoring Plan Sheet (Input Sheet) [Attachment to Project Design Document]

Table 1: Parameters to be monitored *ex post*

(a) Monitoring point No.	(b) Parameters	(c) Description of data	(d) Estimated Values	(e) Units	(f) Monitoring option	(g) Source of data	(h) Measurement methods and procedures	(i) Monitoring frequency	(j) Other comments
(1)	$FC_{PJ,NG,i,p}$	Consumption of natural gas by the project furnace i during the period p		Nm^3/p	Option C	On-site measurements.	On-site measurement by a flow meter. Calibrated according to JIS B 8572-4, OIML R 117-1, or by manufacturer's specification. Data is measured by a flow meter. The flow meter is replaced or calibrated according to JIS B 7556 or the manufacturer's recommendation, unless a type approval, manufacturer's specification, or certification issued by an entity accredited under relevant international/national standards for the flow meter has been prepared by the time of installation.	Monthly	Input on "MPS (input_separate)"
(2)	$D_{op,i,p}$	Number of operating days of the project furnace i during the period p		days	Option C	Operation record		Once at the end of this monitoring period	Input on "MPS (input_separate)"

Table 2: Project-specific parameters to be fixed *ex ante*

(a) Parameters	(b) Description of data	(c) Estimated Values	(d) Units	(e) Source of data	(f) Other comments
EF_{NG}	CO_2 emission factor of natural gas		tCO_2/GJ	Country specific data or 2006 IPCC Guidelines for National Greenhouse Gas Inventories, Volume 2, Table 1.4.	
$\eta_{PJ,i}$	Energy efficiency of the project burner of the project furnace i	-	-	The project-specific value is calculated by the equation in explanatory note 2 using the recommended operational value of air ratio in the manual of the project burner.	Automatically calculated on "MPS(input_separate)"
$\eta_{RE,i}$	Energy efficiency of the reference burner of the reference furnace i	-	-	The project-specific value is calculated by the equation in explanatory note 1 using the recommended operational value of air ratio in the manual of the project burner.	Automatically calculated on "MPS(input_separate)"
m_p	Air ratio for the project burner		-	The recommended operational value in the manual of the project burner.	
m_r	Air ratio for the reference burner	0.00	-	The same value as air ratio for the project burner (m_p) is applied. It is sourced from the recommended operational value in the manual of the project burner.	
$RC_{CAP,i}$	Total maximum rated capacity of auxiliary equipments of the project furnace i		- W	Specification or nameplate of auxiliary equipments of the project furnace.	Input on "MPS(input_separate)"

<p>EF_{elec}</p>	<p>CO₂ emission factor for consumed electricity.</p> <p>When the project furnace consumes only grid electricity or captive electricity, the project participant applies the CO₂ emission factor respectively.</p> <p>When the project furnace may consume both grid electricity and captive electricity, the project participant applies the CO₂ emission factor with lower value.</p> <p>[CO₂ emission factor] For grid electricity: The most recent value available from the source stated in this table at the time of validation For captive electricity: 0.8* [tCO₂/MWh] *The most recent value available from CDM approved small scale methodology AMS-I.A at the time of validation is applied.</p>		<p>tCO₂/MWh</p>	<p>[EF_{grid}] The data is sourced from “Emission Factors of Electricity Interconnection Systems”, National Committee on Clean Development Mechanism (Indonesian DNA for CDM), based on data obtained by Directorate General of Electricity, Ministry of Energy and Mineral Resources, Indonesia, unless otherwise instructed by the Joint Committee.</p> <p>[EF_{captive}] CDM approved small scale methodology AMS-I.A</p>	
--------------------------	---	--	----------------------------	--	--

Table3: Ex-ante estimation of CO₂ emission reductions

CO ₂ emission reductions	Units
0	tCO ₂ /p

[Monitoring option]

Option A	Based on public data which is measured by entities other than the project participants (Data used: publicly recognized data such as statistical data and
Option B	Based on the amount of transaction which is measured directly using measuring equipments (Data used: commercial evidence such as invoices)
Option C	Based on the actual measurement using measuring equipments (Data used: measured values)

		Parameters to be monitored <i>ex post</i>		Project-specific parameters to be fixed <i>ex ante</i>								Ex-ante estimation of emissions			
Parameters	Furnace <i>i</i>	FC _{PJ,NG,i,p}	D _{OP,i,p}	NCV _{NG}	EF _{NG}	RC _{CAP,i}	EF _{elec}	m _p	m _r	η _{PJ,i}	η _{RE,i}	RE _{i,p}	PE _{NG,i,p}	PE _{elec,i,p}	ER _{i,p}
Description of data	Project furnace No.	Consumption of natural gas by the project furnace <i>i</i> during the period <i>p</i>	Number of operating days of the project furnace <i>i</i> during the period <i>p</i>	Net calorific value of natural gas	CO ₂ emission factor of natural gas	Total maximum rated capacity of auxiliary equipments of the project furnace <i>i</i>	CO ₂ emission factor for consumed electricity	Air ratio for the project burner	Air ratio for the reference burner: the same value as air ratio for the project burner (m _p) applied.	Energy efficiency of the project burner of the project furnace <i>i</i>	Energy efficiency of the reference burner of the project furnace <i>i</i>	Reference emissions by the project furnace <i>i</i> during the period <i>p</i>	Project emissions from natural gas consumption by the project furnace <i>i</i> during the period <i>p</i>	Project emissions from electricity consumption by the project furnace <i>i</i> during the period <i>p</i>	Emissions reductions by the project furnace <i>i</i> during the period <i>p</i>
Units	-	Nm ³ /p	day/p	GJ/Nm ³	tCO ₂ /GJ	W	tCO ₂ /MWh	-	-	-	-	tCO ₂ /p	tCO ₂ /p	tCO ₂ /p	tCO ₂ /p
Estimated values	1			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	2			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	3			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	4			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	5			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	6			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	7			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	8			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	9			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	10			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	11			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	12			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	13			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	14			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	15			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	16			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	17			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	18			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	19			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	20			0.036659	0.0000		0	0.00	0.00	0.986	0.957	0.0	0.0	0.0	0.0
	Total	-	-	-	-	0	-	-	-	-	-	0.0	0.0	0.0	0.0

Monitoring Plan Sheet (Calculation Process Sheet) [Attachment to Project Design Document]

1. Calculations for emission reductions		Fuel type	Value	Units	Parameter
Emission reductions during the period p			0.0	tCO ₂ /p	ER _p
2. Calculations for reference emissions					
Reference emissions during the period p			0.0	tCO ₂ /p	RE _p
Reference emissions during the period p (from fossil fuel)		Natural Gas	0.0	tCO ₂ /p	RE _p
3. Calculations of the project emissions					
Project emissions during the period p			0.0	tCO ₂ /p	
Project emissions during the period p (from electricity)		Electricity	0.0	tCO ₂ /p	PE _{elec,p}
Project emissions during the period p (from fossil fuel)		Natural Gas	0.0	tCO ₂ /p	PE _{NG,p}

[List of Default Values]

Net calorific value of natural gas	0.036659	GJ/Nm ³
CO ₂ emission factor of natural gas (IPCC)	0.0561	tCO ₂ /GJ

GW _{NG}	10.694	Nm ³ /Nm ³
C _{1,p}	1.368	kJ/Nm ³ ·degree Celsius
C _{2,p}	1.319	kJ/Nm ³ ·degree Celsius
C _{1,r}	1.455	kJ/Nm ³ ·degree Celsius
C _{2,r}	1.380	kJ/Nm ³ ·degree Celsius
T _{1,p}	300	degree Celsius
T _{1,r}	750	degree Celsius
T ₂	32.6	degree Celsius
A _{0,NG}	9.688	Nm ³ /Nm ³